

BARLOW TYRIE

quality since 1920

Outdoor Furniture Covers Care and Use Guide

Your new cover is designed to provide maximum weather protection with optimal "breathability." Failure to follow this guide may result in the voiding of your cover's warranty.

Proper Care For Your Cover

The life and good looks of your cover depend a great deal on the way you use and how you care for your cover. Even the most durable materials require a certain amount of care, and fabric covers are no exception. Following these suggestions and tips can preserve the life of a cover. Be careful not to drag or yank your cover across any abrasive surfaces, such as cement, or over sharp corners when installing or removing. If the cover is not appropriately fitted, standing water may accumulate on the cover which will weaken the fabric.

Helpful Hints

- If your furniture pieces have any sharp corners or edges, place foam rubber on the sharp edge to reduce risk of puncture or abrasion of your covers.
- For table and chair combinations, placing an object, such as a beach ball, under the centre of the cover can help with water drainage.

Cleaning And Storing Your Cover

Your cover can be hand washed or laundered with a front loading washing machine. Wash in cold water and line dry. DO NOT PLACE IN DRYER. High heat can destroy the fabric (Do Not Dry Clean). You can also spot wash with a soft cloth and mild bleach. Do not use an abrasive cleaner or cloth. It is important to keep your cover clean. This is the best protection against mildew. Your cover is made from material that will not promote the formation of mildew. However, mildew can grow on accumulated dirt and foreign material that collects on the cover. Keep your cover away from trees, shrubbery, vines, etc, as they contain acids that may deteriorate or stain your cover. Always store your cover dry. Folding the cover wet can promote mildew growth that can degrade the fabric. Air dry before folding.

Limited Warranty

Barlow Tyrie covers are warranted to be free of defects from workmanship and materials for a period of two years from the date of purchase. The warranty protects your furniture cover against damage when used under normal conditions and does not cover damage from acts of God, vandalism, neglect, misuse, or improper use such as wind whippage. This warranty is in lieu of all warranties expressed or implied, and under no circumstances shall we be liable for any damages in excess of the cover's original purchase price. Should any trouble occur during the warranty period, please contact Customer Service.

Retain this guide and your receipt for your records. This guide contains important information concerning your cover. Proper use and care of your cover will provide excellent service. If you require any assistance feel free to contact us.

Barlow Tyrie Limited
Braintree
Essex CM7 2RN
England

t: + 44 (0)1376 557 600

f: + 44 (0)870 460 1100

www.teak.com

Barlow Tyrie Inc
1263 Glen Avenue Suite 230
Moorestown NJ 08057 - 8101
USA

t: + 1 856 273 7878

f: + 1 856 273 9199

e: ussales@teak.com

